

Notes Regarding NWare126

If you are upgrading a file generated by NWare 1.1.3 or previous 1.2.x releases:

1. Open the file in NWare 1.2.6
2. Click on Tools > Update All Out of Date Devices... > Yes
3. Drag new NioNode devices from the Devices Tab of NWare 1.2.6 and give them the exact same names and configurations of the existing ones.
4. Delete the old NioNode devices.
5. All controls (Mutes, GPIO, Meters, etc.) in the Project File that were copied from the old NioNodes will be orphaned so replace them with fresh copies from the new NioNodes.
6. Force a recompile of the file by pressing Shift+Control+F9 simultaneously.
7. Save the file!
8. Upgrade the firmware on your NIONS.
 - a. Click on Tools > Update Target Firmware.
 - b. Make sure release_1.2.6_final appears in the Available Firmware box at the bottom of the Update Firmware window.
 - c. Click on the NIONS found in the update window and click on Select For Update for each NION you wish to upgrade.
 - d. Click on the button marked Update Selected.
 - e. Click on OK in the pop-up dialog. The process will be automatic after that.
9. Once the NIONS have rebooted after the firmware update, deploy the Project File normally.